



2. During installation, person who installed should take off any ornaments.










-Component parts





-Tools used






Instruction procedure



7 LH/RH




8




9

9.1




9.2




10 LH/RH


10.1



10.2




10.3




11 LH/RH

11.1




11.2





12 LH/RH


12.1



12.2




13 LH/RH




14 LH/RH


14.1




14.2




15 LH/RH




16 LH/RH




17 LH/RH




18 LH/RH




19 LH




20 LH/RH




21 LH/RH




22 LH/RH




23 LH/RH



23.1




23.2




24 LH/RH


24.1




24.2



24.3





25 LH/RH




Instruction procedure


26 LH/RH




26.1




26.2




26.3




27 LH/RH




27.1




27.2




27.3 LH/RH




28 LH/RH




28.1




28.2



29






30 LH/RH




— Instruction procedure —

31 LH/RH




— Adjust double lock —


Case : 1



RH/LH =




1




No.10

2



No.10


3



RH/LH =




4




Torque 4 Nm. T20


Case : 2



RH/LH =




1




No.10

2




No.10

3



4



RH/LH =



— Instruction procedure for case painting body —

